



Molded All-Weather Assist Handle Install Instructions

(Base Part #: 86400)

PARTS NEEDED:

		
Assist Handle	#8 Pan Head Screws, Coated for Exterior Installation (not provided - recommend two per end cap)	Power Drill

Determine installation location. Make sure there is structural support behind the handle. Failure to install into adequate support will void the warranty and run the risk of pulling the handle out of the wall.

1. Remove endcaps from handle, determine installation location, then mark screw holes and drill pilot holes.



2. Place handle over holes and install using stainless steel screws (not provided).



*To create a seal around the screw holes, ITC recommends using an application specific sealant in pre-drilled holes before installing each screw.

3. Align the end cap cover and snap into place.

