




## Fontana® Exterior Shower Install Instructions

(Part #'s: 97022 & 97023)

### PARTS/TOOLS NEEDED:

	Electric Jigsaw	Power Drill	Teflon Tape	Exterior Caulk
Fontana Exterior Shower Included: rubber washers & mounting Screws	Not Provided	Not Provided	Not Provided	Not Provided

### INSTALLATION INSTRUCTIONS:

- Choose a location that is flat and has a minimum of 10" of rear clearance for hose and water connections.
- Using the dotted line on this sheet as a template, cut the opening for the main body of the shower.
- Apply Teflon tape to center water valve. Use black rubber washers (included) to screw female sprayer hose connection to male collar.
- Insert the shower and mark the four #8 flat head screw holes on the mounting surface.
- Caulk the mounting flange with suitable weather resistant, flexible sealant material.
- Mount shower to opening and drive in screws (included) until secure.
- Connect the faucet set to the on-board water system.

### SPECIFICATIONS:

- Designed for use in a pressure regulated, portable water system with a maximum operating pressure of 40 PSI.
- Maximum flow rate with the faucets fully opened - 2.5GPM.
- DO NOT ALLOW TO FREEZE.
- Do not connect directly to a high pressure residential water supply.



97022-A-5  
Latching Shower



97023-A-5  
Locking Shower



For warranty information please visit [www.itc-manufacturersselect.com/warranty](http://www.itc-manufacturersselect.com/warranty)

ITC Incorporated • 3030 Corporate Grove Dr. • Hudsonville • MI • 49426

Phone: 616-396-1355 • [www.itc-us.com](http://www.itc-us.com) • Doc #: MS9702X • Revision A: 08.02.19