





Illumagrip LED Replacement Installation Instructions

(Base Part #: 86430)

PARTS/TOOLS NEEDED:

	
LED Replacement	Power Drill

IMPORTANT SAFETY INSTRUCTIONS. READ CAREFULLY FOR YOUR PROTECTION AND SAVE ALL INSTRUCTIONS.

*Disconnect power before installing, adding or changing any component.

*To avoid a hazard to children, account for all parts and destroy all packing materials.

*If you are unsure about the installation of this handle, consult a qualified mechanic.

General Installation Notes

*It is the installers' responsibility to verify that the location of the installed IllumaGrip provides enough support for the handle. Any installation other than what is recommended will be the responsibility of the installer and will void the warranty.

1. DISCONNECT POWER


Remove the screws (keep for step 6) holding the handle to the mounting surface and pull handle away from surface. Be careful not to pull too hard on the wiring.



2. Remove the end cap where the LED is housed.



3. Pull the quick disconnect fittings apart. Be careful not to let the wiring fall back into the wall, ITC recommends taping the wires to the wall to prevent this from occurring.



4. Push the LED wires until the LED assembly exits the front of the end cap. Pull the LED completely out of the end cap.



5. Push the new LED assembly into the front of the end cap making sure the wires exit through the back side of the end cap. Connect the quick disconnect fittings to the new assembly.



6. Turn on power to ensure light is working properly. Note: LEDs are polarity sensitive. If the handle does not light try reversing the connections. Push the wiring into the wall and re-attach handle.



For warranty information please visit www.itc-manufacturersselect.com/warranty

ITC Incorporated • 3030 Corporate Grove Dr. • Hudsonville • MI • 49426

Phone: 616-396-1355 • www.itc-us.com • Doc #: MS86430 • Revision A: 09.17.19