




Ventilation Installation Instructions

(Base Part #: 8193X)

PARTS/TOOLS NEEDED:		
	Power Drill & Hole Saw Bit	Jigsaw or Coping Saw
Vent (various options available)	Not Provided	Not Provided

IMPORTANT SAFETY INSTRUCTIONS. READ CAREFULLY FOR YOUR PROTECTION AND SAVE ALL INSTRUCTIONS.

*To avoid a hazard to children, account for all parts and destroy all packing materials.

1. Determine the installation location and drill a hole using a holesaw or jigsaw based on the vent type being installed (see chart below)



2. Insert the air flow vent in the hole and snap into place.



Part Number	Vent Diameter	Cut-Out Dimension
81932-W	3.5"	3.25"
81932SS-HP	3.5"	3.25"
81934/81934-W	3.5"	3.25"

For warranty information please visit www.itc-manufacturersselect.com/warranty

ITC Incorporated • 3030 Corporate Grove Dr. • Hudsonville • MI • 49426

Phone: 616-396-1355 • www.itc-us.com • Doc #: MS8193X • Revision A: 10.11.19